

# **ChemLogic<sup>®</sup> 4 & 8**

Continuous Gas Monitor User Manual

© DOD Technologies, INC  
675 Industrial Drive Bldg. A.  
Cary, IL 60013  
Phone 815.788.5200 • Fax 815.788.5300

## EC DECLARATION OF CONFORMITY EU DECLARATION OF CONFORMITY

DOD TECHNOLOGIES INC.  
675 Industrial Drive – Bldg. A  
Cary, IL 60013  
USA

*Name and address of the company established in European Community and authorized to compile the Technical File.*

ACC - Services Contact  
105 route des pommiers  
Centre Ubidoca  
74370 St Martin Bellevue  
France

DOD TECHNOLOGIES INC. declares under our sole responsibility that the product described as:

Equipment Name: Continuous Gas Monitor  
Equipment Description: Detection and measurement of toxic gases  
Model: CL4/CL8  
Serial number(s): \_\_\_\_\_

Complies with the requirements of the following European Directives:

Machinery Directive 2006/42/EC;  
Electromagnetic Compatibility Directive 2014/30/EU.  
RoHS Directive 2011/65/EU.

Main standards considered :

EN ISO 12100 :2010.  
EN 50271: 2010.  
EN 60204-1:2006 +A1:2009.  
EN 50270: 2006.  
EN 50581: 2012

Name of authorized company representative: Mr. Daniel O'Donnell  
President  
DOD Technologies, INC

*Daniel O'Donnell*

Daniel O'Donnell

Date: 05/25/18  
At: Cary, Illinois USA

## Table of Contents

<b>Chapter 1 – Overview</b>	<b>7</b>
1.1 Introduction	7
1.2 Sampling and Monitoring	7
1.3 Flow Connections	7
1.4 Electrical Connections	8
1.5 Theory of operation	8
1.6 Time Weighted Average (TWA)	8
<b>Chapter 2 – Features</b>	<b>9</b>
2.1 External Layout	9
2.1.1 Warning Labels, Descriptions, & Danger Zones	9
2.1.2 ChemLogic 4 & 8 Danger Zones	10
2.1.3 Status Lamp (OPTIONAL)	11
2.1.4 Output Wiring Knockouts	11
2.1.5 Touch Screen Display	11
2.1.6 Keyed Service Door Access	11
2.1.7 A/C Power & Switch	11
2.1.8 Flow Adjustment	11
2.1.9 ChemLogic Paper Tape	11
2.1.10 Maintenance door	11
2.1.11 Take-up reel	12
2.1.12 Tubing Connections	12
2.2 Maintenance area	12
2.3 Internal Layout – Service area	12
2.4 Password Security	13
2.5 USB Memory Stick	14
<b>Chapter 3 – Installation</b>	<b>15</b>
3.1 Selecting a location	15
3.1.1 Lifting Instructions	15
3.2 Mounting	17
3.3 Sample Tubing	19
3.3.1 Sample Manifold Relocation	19
3.3.2 End of line particulate filters	19
3.4 Exhaust tubing	20
3.5 A/C Power	20
3.6 Output Wiring	20

3.6.1 Standard Output Relay Module Wiring .....	20
3.6.2 Optional 4 to 20ma Output Module Wiring.....	22
3.6.3 Optional 8 Point Relay Module (Item #2-500-012) .....	22
<b>Chapter 4 - Setup &amp; Configuration .....</b>	<b>23</b>
4.1 Set system date and time .....	23
4.2 Gas Selection.....	23
4.3 Alarm Settings .....	23
4.4 Output Relays .....	23
4.5 Concentration Logging .....	23
4.6 Install new tape .....	23
4.7 USB Memory Stick .....	24
4.8 Setup Complete .....	24
<b>Chapter 5 – Basic Operation .....</b>	<b>25</b>
CL4/CL8 Menu Overview .....	25
5.1 Initialization .....	25
5.2 Setup / Main Menu .....	26
5.2.1 Gas & Alarm Settings Menu .....	27
5.2.2 Set Date/Time .....	27
5.2.3 Load Tape .....	28
5.2.4 Flow Adjustment .....	29
5.2.5 Calibration Factors .....	30
5.2.6 Set & Test Outputs .....	31
5.2.7 Factory Settings .....	32
5.2.8 Event History .....	32
5.3 Concentration Log .....	33
5.3.1 Concentration Configuration .....	33
5.4 Analysis Mode .....	34
5.5.1 Point Detail screen.....	35
5.5 USB Memory Stick log .....	35
5.6 Time Weighted Average (TWA) .....	36
<b>Chapter 6 – Maintenance .....</b>	<b>38</b>
6.1 Maintenance Door Access .....	38
6.2 Service Door Access .....	38
6.3 ChemLogic Paper tape .....	38
ChemLogic Paper Tape Installation Procedure .....	39
6.4 End of line particulate filters .....	40
6.5 Flow adjustment.....	41
6.6 USB Memory Stick replacement.....	41

6.7 Apply grease periodically .....	42
6.8 Fuse Replacement .....	42
Chapter 7 – Service & Support.....	43
Appendix A – Accessories / Cassettes.....	44
Appendix B – I/O Connection Detail.....	46
B.1 Standard Output Relay Module .....	46
B.2 4 to 20mA Module (2 Points per Module) (PN: 2-500-011) .....	47
B.2.1 4 to 20mA Module (4 Points per Module) (PN: 2-500-011) .....	48
B.3 8-Point Module (PN: 2-500-012).....	49
B.4 Optional Mechanical Relays .....	50
B.4.1 Optional Mechanical Relay Wiring .....	51
B.5 OPC Interface (PN: 2-500-501) .....	53
Appendix C – System Specifications .....	54
Appendix D – System Event Messages .....	55
Appendix E – Gas Specifications.....	57
Appendix F – USB Memory Stick Data.....	59
F.1 Alarm & Event files (ZG*.CSV).....	59
F.2 TWA Data Logs (TYMMDD.CSV) .....	60
F.3 Concentration Log Files (ZL*.CSV).....	60
F.4 Config File .....	61
Appendix G – ChemLogic Cassettes .....	62
Appendix H – Optic Block Cleaning Procedure .....	63
H.1 Basic Optics Cleaning .....	63
H.2 Advanced Optics Cleaning.....	64

# Chapter 1 – Overview

## 1.1 Introduction

### WARNING:

Operation of the ChemLogic 8 continuous gas detection system without a manual in the native language in its country of operation is illegal. A translated copy of the manual should be requested immediately from DOD Technologies and before installation of the device. Failure to do so may result in severe injury.

Contact:

Phone: +1 815-788-5200

email: [solutions@dodtec.com](mailto:solutions@dodtec.com)

The ChemLogic 4 (CL4) & 8 (CL8) continuous gas detection systems should be used exclusively for the quick detection of toxic, corrosive, and asphyxiant gases for process measurement and personnel safety purposes. Failure to comply with the intended purpose of the device may result in injury or death.

The DOD Technologies ChemLogic 4 (CL4) ChemLogic 8 (CL8) simultaneously monitors eight locations (*called points*) for toxic and corrosive gases. It responds to gases that exceed a programmed alarm level by:

- Triggering visual alarms that warn of high or low concentrations
- Triggering relays or activating analog outputs to external devices
- Displaying the point number, gas type, and gas concentration
- Recording the alarm information and storing it in memory

The CL/4CL8 triggers relays for each individual point for two levels of gas concentrations. These programmable limits are factory-set at 1 TLV and 2 TLV for their respective gases.

Each point may be up to 300 feet (91.44 m) from the CL4/CL8 location. This allows operators to monitor gas concentrations in an area removed from the location where gas may actually be leaking.

The CL4/CL8 provides a fast response to a wide range of gases. It was designed for maximum uptime, so routine maintenance and service can be performed quickly and easily.

The CL4/CL8 uses DOD Technologies ChemLogic paper tape technology for fast and accurate gas detection.

## 1.2 Sampling and Monitoring

The system draws sample flow simultaneously from all eight points. Part of the sample flow is diverted across the ChemLogic tape. All 4/8 channels exhaust through a single port. The ChemLogic 4/8 continuous gas detection system operates at a noise level below 70 dB(A) and does not require hearing protection for operation or work within close proximity. Workplace environment outside the ChemLogic 4/8 system may still require hearing protection. Please consult your safety officer for your recommended safety protocols.

## 1.3 Flow Connections

Flow connections consist of “quick-connect” ports on the top or side of the CL4/CL8 UNIT. There are eight inlets, one for each monitored point, and an exhaust outlet.

## 1.4 Electrical Connections

"Knockout panels" for external electrical connections are provided on the top or right side of the CL4/CL8. The covers are exchangeable to provide top or right-side flexibility.

## 1.5 Theory of operation

The system draws sample flow simultaneously from all four/eight points. Part of the sample flow is diverted across the ChemLogic Tape. The ChemLogic 4/8 uses an advanced optical detection system to measure the light level reflected from the ChemLogic tape. As the target gas is detected, the color of the of the ChemLogic tape changes. This color change results in a loss of reflected light across the ChemLogic tape. This loss of reflected light is detected by the advanced optics system in the ChemLogic 4/8. The ChemLogic 4/8 will then report an appropriate gas concentration reading and/or a gas alarm.

## 1.6 Time Weighted Average (TWA)

During analysis the CL4/CL8 stores the TWA information every 8 hours\* (referred to as a 'cycle'). The system retains the 5 most recent cycles in memory and will save all cycles to the CUSB Memory Stick – if installed. The number of cycles capable of being stored on the USB Memory Stick is only limited by the size of the USB Memory Stick.

**\*NOTE:** If analysis is stopped by the operator or due to any other factor (critical service fault, power interruption, etc.), the TWA information is saved as a separate cycle regardless of how much time has elapsed since the cycle started.



## Chapter 2 – Features

### 2.1 External Layout









Figure 2.1

#### 2.1.1 Warning Labels, Descriptions, & Danger Zones




The below table references all warning labels and their meanings that may be encountered while operating and servicing the ChemLogic 4 and 8 continuous gas detection equipment.

	<p><b><u>WARNING:</u></b> Hot Surface. This surface will be hot to touch and may cause injury. Please avoid or take caution when working near this zone.</p>
	<p><b><u>WARNING:</u></b> Protective Earth Ground. Terminal Intended for connection to external conductor for protection against electric shock in case of fault.</p>
	<p><b><u>ATTENTION:</u></b> Please read operators manual for all instruction for this machine. If manual is not in country's native language, requested updated manual before use of equipment.</p>

	<p><b>WARNING:</b> Electric Shock is possible, please use caution when accessing this zone.</p>
	<p><b>WARNING:</b> Moving Parts and Hand Crushing possible. Please watch hand placement when working near this zone.</p>

## 2.1.2 ChemLogic 4 & 8 Danger Zones

Please be aware of the following danger zones on the ChemLogic 4 and 8 continuous gas detection equipment. Each zone contains warning labels for operator safety. Label meanings/descriptions can be found in the above table

<p><b>A</b></p> 	<p>This danger zone is in the service access point of the unit. Users should be aware of hot surfaces and electrical shock.</p>
<p><b>B</b></p> 	<p>This danger zone is located on the gate assembly. During operation, operators could pinch fingers if not aware of hand placement.</p>
<p><b>C</b></p> 	<p>This danger zone is located on the right exterior of the unit. This area warns of electrical shock areas within the service door of the machine.</p>

### 2.1.3 Status Lamp (OPTIONAL)

The optional status lamp consists of 4 colored lights – Red, Orange, Blue, and Green along with an audible alarm. See Appendix A for ordering information.

### 2.1.4 Output Wiring Knockouts

There are two knockouts available for output wiring located on the top panel near the right side and on the right-side panel near the top.

### 2.1.5 Touch Screen Display

The CL8 uses a full color touch panel LCD display. All menus and data entry are accomplished by touching the appropriate area of the screen – see Chapter 5 “Basic Operation”.

### 2.1.6 Keyed Service Door Access

The door uses a key lock to restrict internal access. See section 2.3 for detailed information on the service area.

### 2.1.7 A/C Power & Switch

A/C power is connected on the right-side panel with a standard cable. The on/off power switch is located adjacent to the power cable connection.

### 2.1.8 Flow Adjustment

Flow adjustments for all 4/8 points are located on the front panel. Refer to section 5.2.d regarding flow adjustment.

### 2.1.9 ChemLogic Paper Tape

ChemLogic paper tapes are accessed by opening the maintenance door. Refer to section 6.3 regarding tape installation/replacement.

### 2.1.10 Maintenance door

The maintenance door allows easy access to the ChemLogic tape for installation and replacement.

**IMPORTANT:** The maintenance door should remain closed and latched except when changing the ChemLogic tape. Do not open the door while in Analysis Mode.

## 2.1.11 Take-up reel

An empty take-up reel is inserted at the time of ChemLogic tape installation (see section 6.3). During installation the previous take-up reel which is full is removed from CL4/CL8 and discarded. The previous ChemLogic tape reel which is now empty should then be used as the next take-up reel.

## 2.1.12 Tubing Connections

Sample tubing and exhaust use a quick connection system for simple installation. The connections may be made on either the top or left side of the CL4/CL8. See section 3.3 for information on connecting the sample and exhaust tubing. See also Appendix C for essential information on transport times for gas from sampling point to the CL4/CL8.

**IMPORTANT:** End of line filters are required at all times on each channel – see Section 6.2.

## 2.2 Maintenance area

The maintenance area allows easy access for changing ChemLogic tape in the CL4/CL8. Figure 2.2 shows the internal layout with the access panel open. See section 3.5 for tape installation.



Figure 2.2

## 2.3 Internal Layout – Service area

Internal access to the CL4/CL8 for installation and service uses the keyed handle located on the right side of the front panel. Figure 2.3 shows the internal layout of the CL4/CL8 with the service door open.



**DANGER:** Turn off the unit and disconnect ~~unplug~~ A/C power to the unit before opening the Service Door.

The door should be opened by trained service personnel (See section 6.2)




Figure 2.3

## 2.4 Password Security

Access to many of the features is controlled through password protection which is entered through the screen displayed in figure 2.4.




Figure 2.4

Whenever someone attempts to access a screen that is password protected, the screen shown in figure 2.2 will appear (see important note below). Several of the setup & configuration screens of the CL4/CL8 require entry of an administrative password. Factory service screens require entry of a service password - see section 7.

**IMPORTANT:** Once a password is entered it remains active for 2 minutes after entry so that it does not need to be repeatedly entered when switching between screens. Please remember that anyone using the touch screen may access restricted screen locations during this time if the machine is left unattended.

**NOTE:** The Administrative Password is included on the first page of this manual. It is suggested that you remove the page and keep in a safe and secure place. If you forget or lose your password please contact DOD Technologies, INC. See Chapter 7 for contact information.

## 2.5 USB Memory Stick

The CL4/CL8 uses a USB Memory Stick to store historical information including concentration logging, event history, configuration information, and TWA data. The use of higher speed USB Memory Stick (2x, etc.) may not be compatible with the CL4/CL8. USB Memory Sticks may be purchased through DOD Technologies – see Appendix A.

## Chapter 3 – Installation

### 3.1 Selecting a location

The CL4/CL8 should be placed in a location as central as possible to the locations being monitored while considering the following restrictions:

- The maximum sample line length is 300 ft. Using the shortest possible sample line length will reduce transport times and increase the response time of the CL4/CL8.  
(see Appendix C)
- A/C power is required to the unit.
- Locate near proper ventilation keeping in mind the maximum length of the exhaust tubing is 25ft.
- The CL4/CL8 requires stable temperature and humidity levels within range to operate properly.

#### Recommendations

Do not place in a location which will expose the CL4/CL8 to moisture, dust, corrosive gas, or any unusual environmental conditions which could damage the unit and/or cause it to operate inaccurately.

#### 3.1.1 Lifting Instructions

It is recommended that installation of this unit requires the help of 3 individuals. Two individuals should lift the unit into its desired location while the third person secures the device into a mounted position. If the device must be manually handled, follow the following steps each time:

##### 1. Size up the Load

- Check if the weight of the object is listed on it
- If not, push, pull, gently kick or rock the object to be moved before you attempt to move it – get a feel for its weight, size and shape
- Check whether the weight is evenly distributed
- Recognize what your own limits are and stick to these limits

Ensure the area is clear

- Work out where the load is going
- Ensure that your intended pathway is clear and free of obstacles
- Make sure that your vision will not be blocked when moving large objects

Position your feet correctly

- Place your feet a comfortable distance apart (shoulder width). A broader base of support increases stability. With a narrow base of support with your feet too close together, you are more likely to lose your balance.
- Point your feet in the direction that you intend to travel
- Always turn with your feet, not your hips or shoulders. Never twist as you move or go to lift!

Get as close to the load as possible

- Walk over to the load – don't stand still and reach for it

Maintain the normal curves in your spine You need to try and work in your power zone – above your knees and below the shoulders

- Keep the back straight and the head looking up
- Half bend the knees and use your leg muscles
- Bend forward at the waist
- Stick your bottom out
- Bend your back as little as possible Keep your head looking up, not down
- Put weight down through your heels, not the toes

Use the correct grip

- Have a firm grip by using the palms and the base of the fingers Don't just use your fingertips as this can cause strain on the hands, wrists and forearms

Lift Smoothly

- Grip the load firmly and hold it close to your body. Keep the heaviest side closest to your body.
- Brace' (tighten) your stomach muscles. Remember to breathe out when you lift. However, remember that bracing the stomach muscles does not mean 'holding your breath'.
- Thrust with the legs - Use the leg muscles to move the load (quadriceps and gluteal muscles).
- They are much bigger and stronger than the back muscles .
- Complete the movement smoothly and without jerkiness.



## 3.2 Mounting

# Front




Figure 3.1

# Right Side




Figure 3.2

# Top




Figure 3.4

Refer to figure 3.1 for dimensional requirements for wall mount. Be sure the CL4/CL8 is properly secured to the wall.

### 3.3 Sample Tubing

Sample tubing may be connected to the CL4/CL8 on the top or left side of the CL4/CL8 (see section 3.3.1). All sample tubes are 1/4" OD x 3/16" ID Teflon FEP (300 ft max length) which may be purchased from DOD Technologies, INC (See Appendix A).

Fully depress each sample tube into the proper hole when attaching. To detach the tube, push on the collet and pull the tubing out

#### 3.3.1 Sample Manifold Relocation

The quick connect system used to attach sample tubing and exhaust may be located on the top or left side of the machine. To move the manifold, Follow the procedures in section 6.2 to open the service door.

- Remove the four (4) mounting screws shown in figure 3.5 to detach the manifold.
- Remove the 4 lock nuts holding the cover plate over the unused manifold opening
- Remove the cover plate
- Align the manifold inside the CL4/CL8 with the holes in the new position
- Replace the screws holding the manifold in place and tighten accordingly.
- Replace the cover plate over the unused opening and secure with the four lock nuts.




Figure 3.5

Sample tubing may be purchased from DOD technologies (see appendix A)

**IMPORTANT:** All sample tubing used with the CL4/CL8 must be 1/4"OD x 3/16" ID FEP Teflon. Use of any other tubing may damage the CL4/CL8 and/or cause inaccurate gas concentration readings.

#### 3.3.2 End of line particulate filters

End of line particulate filters must be installed on all 4/8 sample lines at all times to prevent damage to the unit. Unused lines must either be plugged or have a filter installed. Filters require regular maintenance – see chapter 6.

**IMPORTANT:** All points require filtration to prevent dust accumulation in tubing and internal damage to the CL4/CL8. Dust that collects in the tubing or the internal system may cause sample loss and inaccurate gas concentration readings.

End of line particulate filters may be purchased from DOD technologies (see appendix A)

## 3.4 Exhaust tubing

The exhaust line must be 3/8" OD x 1/4" ID tubing with a maximum length of 25ft. Polyethylene is recommended although polypropylene or Teflon may also be used.

Exhaust tubing may be purchased from DOD technologies (see appendix A)

## 3.5 A/C Power

A 6ft power cord is included – **DO NOT** use extension cords with the CL4/CL8. Longer cords are available from most electrical supply stores.

## 3.6 Output Wiring

Figure 3.2 details the connection method for both the standard relay output module and the optional 4 to 20 ma modules.

See Appendix B for a listing of output module connections.

### 3.6.1 Standard Output Relay Module Wiring

The standard output module requires an external 24V supply connected to V1+/- and V2+/- (see Appendix B). Outputs 0-15 are powered through V1 while outputs 16-31 are powered through V2. Each output can handle up to 0.2 Amps with a total maximum current of 1.6Amps to each group of 16 outputs at any time. See figure 3.6 and 3.7 for information on wiring the CL4/CL8 standard relay outputs.




Figure 3.6




Figure 3.7



**DANGER:** Before performing any wiring modifications, be sure that power to the CL4/CL8 is disconnected and remove the output connector from the output relay block.

Use only AWG22 to AWG18 twisted wire (wire sizes UL1015 and UL1007)  
Strip from .26" to .31" (6.5mm to 8.0mm) from each wire to insert into the connector.

1. To connect the wires to the spring-loaded output connector:
2. Insert the screwdriver into the square shaped hole which will open the round hole for the wire.
3. Continue to hold the screwdriver while inserting the wire into the round shaped hole.
4. While holding the wire in place remove the screwdriver which closes the clamp onto the wire.
5. **IMPORTANT:** Be sure the wire is inserted completely into the hole. Failure to do so could result in system failure, electrical shock.
6. To remove a wire, re-insert the screwdriver in the hole as described in step 1 and gently pull the wire out while the spring is compressed.

### 3.6.2 Optional 4 to 20ma Output Module Wiring

Figure 3.8 details a typical connection to one of the eight (8) 4 to 20ma output connections. See Appendix B for a complete list of terminal connections on the optional 4 to 20ma output block.




Figure 3.8



**DANGER:** Before doing any wiring, modifications be sure that power to the CL4/CL8 is disconnected.

**IMPORTANT:** Verify that all I/O unit terminal screws are securely tightened even if they are not used.

### 3.6.3 Optional 8 Point Relay Module (Item #2-500-012)

See Appendix B for a complete list of terminal connections on the optional output block.

**IMPORTANT:** Verify that all I/O unit terminal screws are securely tightened even if they are not used.



**DANGER:** Before doing any wiring, modifications be sure that power to the CL4/CL8 is disconnected.

## Chapter 4 - Setup & Configuration

### 4.1 Set system date and time

See section 5.2.2

### 4.2 Gas Selection

Each point on the CL4/CL8 must be setup for the appropriate gas and configured accordingly. See section 5.2.1 for information on selecting the gas for each point.

### 4.3 Alarm Settings

See section 5.2.a for information on how to adjust the alarm settings after the gas has been selected for each point.

### 4.4 Output Relays

The CL4/CL8 supports both energized and de-energized relays and may be configured for either latching or non-latching faults/events.

When configured for energized relays, the outputs are normally in a high state and change to a low state when the corresponding fault / alarm occurs. De-energized relays work in the opposite manner. See section 5.2.f. When the power is ON, the Power Loss relay is always in the normally high state.

When latched outputs are selected (section 5.2.f), any fault or alarm that occurs will remain until the 'fault reset' button is touched. If non-latching outputs are selected the output will reset automatically if, and when, the condition that caused the fault/alarm goes away.

**NOTE:** A message is added to the event log each time the 'fault reset' button is touched.

### 4.5 Concentration Logging

Three levels of concentration logging can be configured in the CL4/CL8.

1. >0 - All concentrations detected  $\geq$  LDL are added to the concentration log.
2. AP1 - Anytime alarm level 1 is reached, the concentrations are added to the log.
3. AP2 - Anytime alarm level 2 is reached, the concentrations are added to the log.

Regardless of which point the gas is detected on, all CL4/CL8 points are logged as long as the trigger is active. For AP1 or AP2 logging the system will continue to log concentrations as long as the alarm level is active. If latching faults are enabled the system will continue to log until the 'fault reset' button is touched. See section 5.3

### 4.6 Install new tape

See section 6.3 for installation instructions.

## 4.7 USB Memory Stick

The use of a USB Memory Stick is highly recommended to retain historical and performance information including events, alarms, and gas concentrations. USB Memory Sticks are available from DOD technologies (see Appendix A) and at most retail electronic stores. See section 6.4 for information on inserting and replacing a USB Memory Stick. See also Appendix F for information on the data stored on the USB Memory Stick.

## 4.8 Setup Complete

Enter analysis.



## Chapter 5 – Basic Operation

### CL4/CL8 Menu Overview

<ul style="list-style-type: none"> <li>I. Initialization (Power on) (<b>sec. 5.1</b>) <ul style="list-style-type: none"> <li>a. Setup Mode</li> <li>b. Timer</li> </ul> </li> <li>II. Setup (11 button menu) (<b>sec. 5.2</b>) <ul style="list-style-type: none"> <li>a. Gas &amp; Alarm Settings <ul style="list-style-type: none"> <li>i. Points 1-4</li> <li>ii. Points 5-8</li> </ul> </li> <li>b. Set Date/Time</li> <li>c. Load Tape</li> <li>d. Adjust Flow</li> <li>e. *Calibration Factors</li> <li>f. *Set/Test Outputs</li> <li>g. **Factory Settings</li> <li>h. Events History</li> <li>i. Fault Reset</li> <li>j. Start Analysis</li> </ul> </li> <li>III. Concentration Log (<b>sec. 5.3</b>)</li> <li>IV. Analysis (5 buttons &amp; 8 points w/detail) (<b>sec. 5.4</b>) <ul style="list-style-type: none"> <li>a. Setup</li> <li>b. Concentration Log</li> <li>c. Event History</li> <li>d. Silence</li> <li>e. Fault Reset</li> <li>f. Point Detail (1-8)</li> </ul> </li> <li>V. USB Memory Log (<b>sec. 5.5</b>)</li> <li>VI. Time weight average (<b>sec. 5.6</b>)</li> </ul>	<p style="text-align: center;"><b>Legend</b></p> <div style="border: 1px solid black; padding: 10px; text-align: center;"> <p>User Screens (No Password Required)</p> <p>*Administrative Screens (Administrator Password Required)</p> <p>**Service Screens (Service Password Required)</p> </div>
--	--

### 5.1 Initialization

When the CL4/CL8 is powered on it will begin with an initialization screen (figure 5.2) which is followed by the restart screen (figure 5.3).




Figure 5.2

Automatic  
→



Figure 5.3

If the operator touches the 'SETUP MODE' button before the timer reaches 0 the Setup screen appears (section 5.2) otherwise after a timeout the system will start analysis (section 5.4)

## 5.2 Setup / Main Menu

The setup menu is accessed either by touching the 'SETUP MODE' button on power up (section 5.1) or by touching 'SETUP' from the analysis screen (section 5.5). Figure 5.4 below shows the setup screen and explains the various buttons.




Figure 5.4

## 5.2.1 Gas & Alarm Settings Menu

Touching the 'GAS & ALARM SETTINGS' button on the setup screen brings up the screen shown on the left in figure 5.5 which displays the configuration of points 1-5. Touching the 'NEXT' button will bring up the screen shown on the right of figure 5.5 which displays the configuration of points 5-8. Touching the 'BACK' button will then return to the SETUP screen.




Figure 5.5

Touching the 'CHANGE GAS' button brings up the gas selection menu from which you may either select a new gas or touch the 'Cancel' button. Touching any of the alarm level numeric displays will bring up the keypad to change the alarm level. The valid alarm levels are listed in Appendix X for each gas. An invalid alarm level entry will bring up an error message.

The toggle switch to the right of each point allows the individual points to be disabled when not in use. The word 'DISABLED' will then appear on the analysis screen for that point and no calculations will be made.

## 5.2.2 Set Date/Time

Touching the 'SET DATE/TIME' button on the setup screen brings up the screen shown in figure 5.6.




Figure 5.6

Touching any of the numeric displays for Month, Day, Year, and Time will bring up the numeric entry keypad. The time must be entered in 24-hour (Military) time format. Touch the 'BACK' button to return to the setup menu.

**IMPORTANT:** After entering the new date & time you must touch the "Apply Changes" button to update the system date/time.

### 5.2.3 Load Tape

Touching the 'LOAD TAPE' button on the setup screen brings up the screen shown in figure 5.7.




Figure 5.7

**IMPORTANT:** Each time a new tape is loaded into the CL4/CL8 the 'RESET COUNTER' button must be touched to accurately track tape usage.

Each time the 'OPEN/CLOSE GATE' button is touched, the gate will open or close appropriately. If the gate is currently closed, touching the button will open the gate. If the gate is currently open\* touching the button will close the gate.

**NOTE:** If the gate is not completely open touching the button will open the gate to the proper open position. Touch the button again to close.

To Exit the screen optics verification is required. When the 'Verify Optics', button is touched the machine will verify the tape is aligned correctly and the optics are calibrated appropriately. During this time a 'ONE MOMENT PLEASE' window will appear. When verification is complete one of the two screens in figure 5.8 will appear.



Figure 5.8

If successful touch the "OK" button to return to the setup menu. If unsuccessful verify that the tape is installed and aligned correctly by using the 'OPEN/CLOSE GATE' button as needed. Once you have verified that the tape is installed correctly you can touch the 'YES' button to recalibrate the optics for the new tape or press 'NO' to return to the setup menu.

**IMPORTANT :** If you choose 'NO' when asked to calibrate the optics as shown to the right of figure 5.8 the CL4/CL8 may not function properly. Contact DOD Technologies for more information.

## 5.2.4 Flow Adjustment

Touching the 'ADJUST FLOW' button on the setup screen brings up the screen shown in figure 5.9 along with advancing the tape and turning the pump on. Use the corresponding flow adjustment knobs located on the front panel to adjust the flow so that each level is as close as possible to the black line in the middle of the green section.

**\*NOTE:** There may be a slight delay between the time the knob is turned, and the updated reading is reflected on the screen. Adjust the knob slowly and wait a few seconds to verify that the level is accurate.




Figure 5.9

Touch the 'BACK' button to return to the setup menu.

## 5.2.5 Calibration Factors

Touching the 'CALIBRATION FACTORS' button on the setup screen brings up the screen shown in figure 5.10. This screen requires administrator password access. Contact DOD (see chapter 7) for information on the use of Calibration Factors.




Figure 5.10



Touching any of the numeric displays for any of the channels will bring up the numeric entry keypad. The value entered must be between 0.5 and 2.000 for each channel.

**NOTE:** This screen requires the Administrator password for access – See section 2.4

## 5.2.6 Set & Test Outputs

Touching the 'SET/TEST OUTPUTS' button on the setup screen brings up the screen shown in figure 5.11. This allows the user to test relays and analog outputs.

Two other features on this screen:

1. Require a password to exit analysis – If enabled the level 1 password must be used for anyone to exit the analysis screen. When disabled a simple "Are you sure?" window appears.
2. Idle Timeout – Set from 1-60 minutes to trigger a fault when the machine is left in idle. Setting this to 0 minutes disables the fault.

**CAUTION:** Activating these outputs will trigger any connected alarms




Figure 5.11

### 5.2.7 Factory Settings

This button is reserved for technical service and requires a service password. Contact DOD Technologies, INC (section 7) for service information.

### 5.2.8 Event History

Touching the 'EVENT HISTORY' button on the setup screen brings up the screen shown in figure 5.11.




Figure 5.12

The event history is display with the most recent event/alarm at the top using the color coding listed in table 5.1.

Table 5.1

Green	Normal operation messages
Yellow	Fault messages
Blue	Informational display messages – non-critical
Orange	Critical Service messages
Red	Gas alarm messages

Touch the 'BACK' button to return to the setup menu.



## 5.3 Concentration Log

Touching the 'CONC LOG' button on the Event History screen (section 5.2.9) will bring up the screen shown in figure 5.13.




Figure 5.13

The log displays the concentration on each point when the trigger criteria is met. If you select >0 the system will log all CL4/CL8 points when any of the points have a concentration reading which is >LDL for the gas selected. (See appendix E).

The buttons on the right of the screen allow scrolling through the most recently logged readings. Touch the configuration button to set the logging parameters.

### 5.3.1 Concentration Configuration

Figures 5.12.b shows the concentration configuration screen. Four levels of logging area available depending on your needs.

1. Alarm Level 2 – Logging on when any channel is above alarm level 2
2. Alarm Level 1 – Logging on when any channel is above alarm level 1.
3. 0 – Logging on when any channel is above 0
4. Continuous – Logging always on (not recommended)




Figure 5.12b

In addition, the logging interval can be adjusted from the default of 2 seconds to a maximum of 10 minutes (600 seconds).

## 5.4 Analysis Mode

Figure 5.13 shows the main analysis screen which is entered either automatically during power on or by touching the 'START ANALYSIS' button on the setup screen. Figure 5.14 shows the main analysis screen with a detailed view of the information on point 3.




Figure 5.13




Figure 5.14

At the bottom of the analysis screen on the right side is the current date & time and a message box below it. The message box will either display the blinking message 'NO USB Memory Stick' or will be blank if a USB Memory Stick is inserted in the machine. (See section 2.5.)

To display detailed information on any point touch along the left-hand side from the point # to the square box above it which will bring up the point detail screen (section 5.5.1).

Touch the 'BACK' button to return to the setup menu.

## 5.5.1 Point Detail screen

Touching a point # on the analysis screen (Section 5.4) will bring up the point detail screen shown in figure 5.15




Figure 5.15

The information on the point detail screen is updated in real time while in analysis mode. Alarm levels may be changed by touching the numeric display area for the appropriate alarm. Similarly, the comments related to this point may be edited by touching anywhere in the box displayed for comments.

**NOTE:** The display of the current flow may not be immediately displayed on this screen. It is recommended that the flow adjustment screen (section 5.2.4) be used for all flow calibration.

## 5.5 USB Memory Stick log

Figure 5.16 shows the 'CF Log' which is displayed by touching the 'CF Files' button on the concentration log (Section 5.3). This screen allows the user to browse everything contained on the USB Memory Stick currently inserted. (Note – if no USB Memory Stick is present or there is an error reading the card, the left selection screen will appear blank). To initiate the display touch 'DISP'.




Figure 5.16

## 5.6 Time Weighted Average (TWA)

Touching the 'TWA' button on the concentration log screen (section 5.3) brings up the TWA screen shown in figure 5.17.




Figure 5.17

The first screen displays the current TWA information including the minutes and seconds elapsed since the cycle started. The CL4/CL8 retains the most recent 5 analysis cycles (up to 40 hours) in addition to the current cycle in memory. The previous cycles are accessed by touching the 'View History' button which brings up the screen shown in the lower right of figure 5.17. Use the up and down arrows to review the previous 5 cycles in this screen.

## Chapter 6 – Maintenance

It is recommended for complete safety that the ChemLogic 4/8 continuous gas detection system be serviced on-site every 6 months by a certified DOD Service Engineer or by submitting the unit to the manufacturer for routine maintenance. A certificate of repair should be received and kept with operation documents of the machine. Any malfunctions in the device should be reported and corrected before further use.

### 6.1 Maintenance Door Access

The maintenance door is used to access the ChemLogic tape. To open the maintenance door simply turn the maintenance door locking knob counterclockwise until it is unscrewed from the main panel. The door can then be opened.

When maintenance is complete be sure to close the maintenance door and hand tighten the maintenance door locking knob (clockwise) to secure the door.

**IMPORTANT:** The maintenance door should remain securely latched at all times except when servicing the ChemLogic tape.

### 6.2 Service Door Access



**DANGER:** Turn off the unit and unplug A/C power to the unit before opening the Service Door.

To open the door:

1. Insert the key provided into the slot and rotate counter clockwise to unlock the unit.
2. Turn the latch counterclockwise to unlatch the door.
3. Open the door for service as required.

When service is complete be sure to close the service door and secure the keyed latch to the closed position. Verify that the service door cannot be pulled open – secure the door using the key to lock the door.

**IMPORTANT:** The service door must remain securely latched at all times when not servicing the unit. Verify that the latch is secure and use the keyed lock to prevent unauthorized access.

### 6.3 ChemLogic Paper tape

The ChemLogic paper tape has an expiration date printed on the label. Expired tape should be disposed of and replaced with new tape to assure proper gas concentration readings. Each DOD ChemLogic tape cartridges will last for 60 days under normal usage. See Appendix A for ordering information.

## ChemLogic Paper Tape Installation Procedure

- A. From the setup menu touch the 'Load Tape' button (section 5.2.3)
- B. Open the maintenance door. (Section 6.1)
- C. On the screen touch the 'OPEN/CLOSE GATE' button to open the gate
- D. Remove the old take-up reel by gently pulling and dispose of properly
- E. Remove the empty tape reel and install on top as the new take-up reel.
- F. Secure the new ChemLogic tape reel on the bottom as shown in figure 6.1. The tape should be around the bottom in a clockwise direction as shown.
- G. Feed the tape as shown with the arrows in figure 6.1.
  1. From the bottom reel
  2. Around the bottom tape guide
  3. Through the opening between the optic blocks
  4. Between the rubber roller and the capstan
  5. Around the top of the upper tape guide
  6. Fold the end of the tape and insert into the slot in the empty tape reel. Be sure the tape is wound clockwise around the take-up reel.




Figure 6.1

- H. Turn the upper wheel clockwise at least 2 full turns to secure the tape
- I. On the screen touch the 'OPEN/CLOSE GATE' button to close the gate
- J. On the screen touch the 'Reset Counter' button. (See section 5.2.3)

**Warning:** Keep fingers clear during tape advance.



## 6.4 End of line particulate filters

End of line (point of detection) particulate filters which protect the CL4/CL8 from damage are required on all 4/8 points including points not being monitored. Table 6.1 details the type of filter required for each gas – see also figure 6.2. Filters must be replaced on a regular basis as shown in the table. Filter orientation is not critical in either application.

**IMPORTANT:** All points require filtration to prevent dust accumulation in tubing and internal damage to the CL4/CL8. Dust that collects in the tubing or the internal system may cause sample loss and inaccurate gas concentration readings.

Table 6.1

Gas	Description	Suggested Replacement	DOD Filter Part #
AsH <sub>3</sub>	Arsine	6 Months	780248
B <sub>2</sub> H <sub>6</sub>	Diborane	6 Months	780248
GeH <sub>4</sub>	Germane	6 Months	780248
H <sub>2</sub> SE	Hydrogen Selenide	6 Months	780248
PH <sub>3</sub>	Phosphine	6 Months	780248
SiH <sub>4</sub>	Silane	6 Months	780248
TBA	Tertiary-Butyl-Arsine	6 Months	780248
H <sub>2</sub> S	Hydrogen Sulfide	6 Months	780248
HCL	Hydrogen Chloride	1 Month (membrane)	60009 (Housing) 60010 (membrane) OR 2-800-013
HF	Hydrogen Fluoride	1 Month (membrane)	60009 (Housing) 60010 (membrane) OR 2-800-013
BF <sub>3</sub>	Boron Trifluoride	1 Month (membrane)	60009 (Housing) 60010 (membrane) OR 2-800-013
HBR	Hydrogen Bromide	1 Month (membrane)	60009 (Housing) 60010 (membrane) OR 2-800-013
COCL <sub>2</sub>	Phosgene	6 Months	780248



		
<p>Mineral Acids Filter</p> <p>Part Numbers: Blue Housing: 60009 Filter Membrane: 60010</p>	<p>Hydrides &amp; Phosgene Filter</p> <p>Part Number: 780248</p>	<p>Mineral Acids Disposable Filter</p> <p>Part Number 2-800-013</p>

Figure 6.2

## 6.5 Flow adjustment

Each channel should be adjusted whenever a new ChemLogic tape or particulate filter is installed. See section 5.2.4

## 6.6 USB Memory Stick replacement

It is highly recommended to keep a USB Memory Stick inserted in the unit at all times. The lower right corner of the analysis screen will show when a card is properly inserted (see section 5.4) To insert or replace a USB Memory Stick follow these steps below.

- 1) Locate USB slot on middle center of the HMI. It is marked USB.
- 2) Removal:
  - a) Pull USB Memory Stick straight down
- 3) Insertion:

- a) Push the USB Memory Stick straight up ensuring the USB Memory Stick and slot are aligned properly.





Figure 6.3


Section 5.5 describes viewing the files stored on the USB Memory Stick on the touch screen. Appendix F details the data stored on the USB Memory Stick and how to access it on a personal computer.

## 6.7 Apply grease periodically

The cam attached to the gate motor should be greased every 6 months to prevent wear. Apply a small amount of number 2 type petroleum or synthetic grease (such as McMaster Carr #1378K27) to the rounded portion of the cam. – See Figure 6.4



Top of gate mechanism



Bottom of gate mechanism

Figure 6.4 -Grease may be applied either from the top of the gate mechanism or the bottom.

## 6.8 Fuse Replacement

The system power is fused with a 2 amp fast-acting (5x20mm) fuse.

## Chapter 7 – Service & Support

For information on service and support for your CL4/CL8 contact DOD Technologies, INC. using the information below.

### For Permanent discontinuation:

Please contact DOD Technologies for the safe return of your equipment. All discontinued units will be accepted back by DOD Technologies so proper recycling may take place. For information on how to return the unit contact us using the below information:

### Phone Support

M-F 8:30am – 5pm (Central Time Zone)

**815.788.5200**

### Service Center

675 Industrial Drive Bldg. A.

Cary, IL 60013

### Visit our website

[www.dodtec.com](http://www.dodtec.com)

## Appendix A – Accessories / Cassettes

Part Number	Spare Parts for CL8 Description	Qty	Price
2-100-A06	CL8 Sample Inlet Manifold Assy	1	\$230.00
2-100-A07	CL8 Needle Valve flow (w/o needle valves)	1	\$700.00
2-100-A12	CL1 & CL8 Gate Open Assy with Cam	1	\$596.00
2-100-A13	CL1 & CL8 Tape Advance Assy	1	\$250.00
2-800-A14-8	Assembly Transducer PCB (new style)	1	\$380.00
2-100-A26	Assy Micro Switch Field Upgrade	1	\$55.00
2-100-A31	Assy PCB CL8 Interconnect	1	\$65.00
2-100-A39	CL8 PUMP ASSY - TYPE B - 115 VAC - Side Port	1	\$370.00
2-100-A40	CL8 PUMP ASSY - TYPE B - 230 VAC - Side Port	1	\$410.00
2-100-A42	CL8 PUMP ASSY - TYPE A - 230 VAC	1	\$410.00
2-200-238	Type B Pump Rebuild Kit	N/A	\$79.00
2-200-001	Graphic Logic Controller - 24 VDC	1	\$3,750.00
2-200-002	Module 16 in 16 sink out	1	\$450.00
2-200-003	Module 32 in/out Sink	1	\$550.00
9-200-004	Fuse 2A 5X20 Fast Acting	1	\$7.00
2-200-006	Power Entry Module	1	\$88.00
2-200-011	Power Supply 24VDC 120W DIN	1	\$275.00
2-200-012	Power Supply 5VDC 1.5Amp DIN	1	\$108.00
2-200-013	Relay Socket	1	\$28.00
2-200-108	Relay 24VDC Lighted CL8	1	\$35.00
2-100-A77	CL8 Regulator Assy 12VDC 3A	1	\$45.00
2-200-080	Module 2 Channel 4-20mA	4	\$550.00
2-300-001	Drive Belt 113 Links CL8, CL96	2	\$35.00
2-300-002	Bearing One-Way Needle	2	\$30.00
2-300-003	Drive Roller 1-1/2"OD	1	\$75.00
2-300-004	Gear 24 Teeth Take-Up	1	\$45.00
2-300-005	Needle Valve Manifold Mount	8	\$75.00
2-300-010	Drive Belt 94 Links CL8 - Capstan to Drive M	1	\$35.00
2-100-A03-8	CL8 Optic Block Assembly with Software	2	\$820.00
2-100-A05	Assy CL8 Tubing Harness (Includes all of the Teflon tubes to and from optics and black tubes to and from transducer)	N/A	\$100.00
2-100-A73	Assy CL8 exhaust tubing upgrade (Pump tubing)	N/A	\$45.00
60009	Assy Filter Housing for Corrosive Gases	N/A	\$105.00
60010	Teflon Membranes for 60009 - 100Pk - 47mm	N/A	\$275.00
2-500-502	Teflon Membranes for 60009 - 10pk - 47mm	N/A	\$50.00

780249	End of Line Particulate Filter (1.44 OD x 4.61 Long)	N/A	\$21.00
780248	End of Line Particulate Filter for non-corrosive gases	N/A	\$11.00
2-800-013	End of Line Particulate Filter for corrosive gases	N/A	\$35.00
<b>Spare Parts for Pyrolyzer Option Only</b>			
2-200-090	4- Point Pyrolyzer Assembly	2	\$3,500.00
	Includes (2) 2-200-091, (2) 2-200-092, (1) 2-200-107		
2-200-095	15 VDC Power Supply	2	\$410.00
<b>Individual Spare Parts for Pyrolyzer Option</b>			
2-200-091	Pyrolyzer Control PCB with Photodiode	8	\$500.00
2-200-092	Pyrolyzer Oven (includes filament, quartz tube, and Teflon block)	8	\$500.00
2-200-107	Fan Pyrolyzer	2	\$75.00

## Appendix B – I/O Connection Detail

### B.1 Standard Output Relay Module

Description	Output
Point 1 Alarm Level 1	0
Point 1 Alarm Level 2	1
Point 2 Alarm Level 1	2
Point 2 Alarm Level 2	3
Point 3 Alarm Level 1	4
Point 3 Alarm Level 2	5
Point 4 Alarm Level 1	6
Point 4 Alarm Level 2	7
Point 5 Alarm Level 1	8
Point 5 Alarm Level 2	9
Point 6 Alarm Level 1	10
Point 6 Alarm Level 2	11
Point 7 Alarm Level 1	12
Point 7 Alarm Level 2	13
Point 8 Alarm Level 1	14
Point 8 Alarm Level 2	15
Critical Fault	16
Watchdog	17
Power On	18
Analysis Mode	19
General Fault	20
Gas Alarm Level 1	21
Gas Alarm Level 2	22
Critical Fault (*)	23
General Fault (*)	24
Gas Alarm Level 1 (*)	25
Gas Alarm Level 2 (*)	26
Blue Light	27
Audible Alarm	28
Green Light	29
Orange Light	30
Red Light	31

(\*) Can be Energized / De-Energized


Output Relay Connector

0	1	Output
2	3	
4	5	
6	7	
8	9	
10	11	
12	13	
14	15	
V1 +	V1 -	
16	17	
18	19	
20	21	
22	23	
24	25	
26	27	
28	29	
30	31	
V2 +	V2 -	

Connect 24 Volt supply to V1 +/- and V2 +/- (See Connector diagram.)

Outputs 0-15 use common ground (V1 -)  
Outputs 16-31 use common ground (V2 -)

0.2 Amp per output max current  
Outputs 0-15 Max current 1.6A  
Outputs 16-31 Max current 1.6A




## B.2 4 to 20mA Module (2 Points per Module) (PN: 2-500-011)

TR+	SLD	+24V		V1+	I1+	V2+	I2+
TR-	0V		FG	AG1	FG	AG2	FG

Labeled connector on each 4 to 20ma Module.

**IMPORTANT:** Use only connections above shown in grey. Other connections are pre-wired in the CL4/CL8.



### 4-20 ma Output Circuit Wiring.

Description	Module	Connection	Symbol
Point 1 4 to 20 ma	1	I1+	I+
	1	AG1	AG
	1	FG	FG
Point 2 4 to 20 ma	1	I2+	I+
	1	AG2	AG
	1	FG	FG
Point 3 4 to 20 ma	2	I3+	I+
	2	AG1	AG
	2	FG	FG
Point 4 4 to 20 ma	2	I4+	I+
	2	AG2	AG
	2	FG	FG
Point 5 4 to 20 ma	3	I1+	I+
	3	AG1	AG
	3	FG	FG
Point 6 4 to 20 ma	3	I2+	I+
	3	AG2	AG
	3	FG	FG
Point 7 4 to 20 ma	4	I3+	I+
	4	AG1	AG
	4	FG	FG
Point 8 4 to 20 ma	4	I4+	I+
	4	AG2	AG
	4	FG	FG


Module	Address
Module 1	6
Module 2	8
Module 3	10
Module 4	12

## B.2.1 4 to 20mA Module (4 Points per Module) (PN: 2-500-011)

TR+	SLD	+24V	AG1	V2+	I2+	V3+	I3+	AG4	FG*
TR-	0V	V1+	I1+	AG2	FG*	AG3	V4+	I4+	GND

Labeled connector on each 4 to 20ma Module. \*Each 'FG' terminal may be used for 2 points.

**IMPORTANT:** Use only connections above shown in grey. Other connections are pre-wired in the CL4/CL8.



### 4-20 ma Output Circuit Wiring.

Description	Module	Connection	Symbol
Point 1 4 to 20 ma	1	I1+	I+
	1	AG1	AG
	1	FG*	FG
Point 2 4 to 20 ma	1	I2+	I+
	1	AG2	AG
	1	FG*	FG
Point 3 4 to 20 ma	1	I3+	I+
	1	AG3	AG
	1	FG*	FG
Point 4 4 to 20 ma	1	I4+	I+
	1	AG4	AG
	1	FG*	FG
Point 5 4 to 20 ma	2	I1+	I+
	2	AG1	AG
	2	FG*	FG
Point 6 4 to 20 ma	2	I2+	I+
	2	AG2	AG
	2	FG*	FG
Point 7 4 to 20 ma	2	I3+	I+
	2	AG3	AG
	2	FG*	FG
Point 8 4 to 20 ma	2	I4+	I+
	2	AG4	AG
	2	FG*	FG

Module	Address
Module 1	9
Module 2	D




## B.3 8-Point Module (PN: 2-500-012)

TR+	SLD	+24V	V+					COM				
TR-	0V	V-			0	1	2	3	4	5	6	7

Labeled connector on each 8 Point Relay Module. See drawing below.

**IMPORTANT:** Use only connections above shown in grey. Other connections are pre-wired in the CL8.

Module	Address
8 Point Relay Module	7



## B.4 Optional Mechanical Relays

Description	Output
Point 1 Alarm Level 1	0
Point 1 Alarm Level 2	1
Point 2 Alarm Level 1	2
Point 2 Alarm Level 2	3
Point 3 Alarm Level 1	4
Point 3 Alarm Level 2	5
Point 4 Alarm Level 1	6
Point 4 Alarm Level 2	7
Point 5 Alarm Level 1	8
Point 5 Alarm Level 2	9
Point 6 Alarm Level 1	10
Point 6 Alarm Level 2	11
Point 7 Alarm Level 1	12
Point 7 Alarm Level 2	13
Point 8 Alarm Level 1	14
Point 8 Alarm Level 2	15
Critical Fault (Fault)	16
SPARE (UNUSED)	17
Power On	18
Analysis Mode (Out of Analysis)	19
General Fault (Maintenance)	20
Gas Alarm Level 1	21
Gas Alarm Level 2	22

### NOTES


240 VAC max per relay

Xx Amps max current per relay

## B.4.1 Optional Mechanical Relay Wiring

Below is a typical wiring diagram to connect a Form C Relay to any of the sinking outputs described in Appendix Section B.1 Note: You must connect 24V + to both V1+ / V2+ AND connect 24V- to both V1- / V2- on the connector as shown below.

0	1	Output
2	3	
4	5	
6	7	
8	9	
10	11	
12	13	
14	15	
V1 +	V1 -	
16	17	
18	19	
20	21	
22	23	
24	25	
26	27	
28	29	
30	31	
V2 +	V2 -	



## B.5 OPC Interface (PN: 2-500-501)

Use the RJ-45 connector pictured below to connect the CL4/CL8 to the I/P:network when the optional OPC Interface (OPC I/F) is specified. The connector is located on the inside of the machine next to the top DIN-rail.



## Appendix C – System Specifications

Physical Dimensions	
Height	20"
Width	20"
Depth	11.3"
Weight	Approx. 70 lbs.
Tubing	
Exhaust Line (1)	3/8" OD x 5/16" ID Polypropylene (25 ft. max length)
Sample Lines (8)	1/ 4" OD x 3/16" ID Teflon FEP (300 ft. max length)
Power	
A/C Power	(100-120 VAC, 50/60 HZ) ( 220/240 VAC, 50/60 HZ)
Standard Output Relays	
Rated Output Voltage	DC 24V
Rated Output Voltage Range	DC 20.4V - 28.8V
Maximum Load Voltage	0.2A/Connection (1.6A maximum pts 0-15 & pts 16)
Output Protection	None
Transport	
Transport Times	Approx. 36 Seconds at 250 ft. 18 seconds at 125 ft.

## Appendix D – System Event Messages

COLOR CODING	
RED	Gas Alarm
ORANGE	Service Fault (critical)
YELLOW	Maintenance (non-critical)
BLUE	Information Message
GREEN	Status (during analysis)

Event Code	Message	Corrective Action
30000	System Communication Failure	Service required
30001	All Points Are Disabled	Enable 1 or more points - sections 4.2.a
30002	Low flow multiple points	Check pump, gate, or adjust flow
30003	Gate Close Fault	Gate home switch stuck or gate not moving
30004	Gate open Fault	Check gate home switch and/or mechanism
30005	High background Fault	Check/replace tape
30006	I/O Failure - Check wiring	Check RS-485 wiring
30007	No Gas Family Selected	Service required
30008	Pump failure	Check pump wiring/flow
30009	Tape Advance Fault	Tape switch not activated before timeout
30010	Optic 1 Communication Error	Check Wiring or Optic 1
30011	Optic 2 Communication Error	Check Wiring or Optic 2
30012	High Background Tape Advance Fault	Check/replace tape
30013	LED Failure Optic 1	Possible Tape alignment problem
30014	Warning : Default values restored	Reconfigure & Calibrate
30015	Pump Timeout Error	Pump failure or system problem
30016	Tape Advance Problem	Service required
30017	Optic 1 LED Failure	Service required
30018	Optic 2 LED Failure	Service required
30019	Optic Supply Voltage Failure	Service required
30020	Optic reference validation fault	Service required
30021	LED Failure Optic 2	Service required
30022	Complete Optic Low Flow all Pt 1-4	Check gate closure
30023	Complete Optic Low Flow all Pt 5-8	Check gate closure
30024	LED Calibration error	
50000	Chemlogic tape supply low	Change Tape
50001	Pt X High Flow	Flow Adjustment - Section 4.2.d
50009	Pt X Low Flow	Flow Adjustment - Section 4.2.d
60000	8 Hour - conc. detected	
60010	Last analysis - Conc. detected	
60011	Alarms & Faults Reset	
60012	Error Transferring TWA/Analysis Summary	
60013	Flow Fluctuation	
60014	Maximum # of Ref fluctuations	

60015	LED Fluctuation fault	
60016	Temperature fluctuation - O1	
60017	Temperature fluctuation - O2	
60018	K Factor - all pts = 1.000	
60019	K Factor - some pts <> 1.000	
60020	Reference fluctuation point X	
60028	Power UP Time	
60029	PT X Disabled	
60030	Tape Counter Reset	
60031	Simulation Mode	
60032	Simulation Enabled Point 1	
70000	DIAGNOSTIC STATUS OK	
70001	8 Hour - no conc. all points.	
70002	Analysis Start Time	
70003	Last analysis - no Conc. found	



## Appendix E – Gas Specifications

Family	Gas	Range	LDL	Full Scale	Alarm Level 1 Default	Alarm Level 2 Default	Tape Part #
120 Day Ammonia	NH3	NH3(0-75)ppm	1.2	75	25	50	1-700-012
120 Day Hydrides	AsH3	AsH3(0-500)ppb	5.4	500	50	100	1-300-012
120 Day Hydrides	B2H6	B2H6(0-1000)ppb	6.0	1000	100	200	1-300-012
120 Day Hydrides	PH3	PH3(0-1500)ppb	4.9	1500	300	600	1-300-012
120 Day Hydrides	SiH4	SiH4(0-50)ppm	0.2	50	5	10	1-300-012
120 Day Hydrides	H2S	H2S(0-20)ppm	0.2	20	10	20	1-300-012
120 Day Hydrides	H2S	H2S(0-5)ppm	0.1	5	0.5	1	1-300-012
120 Day Hydrides	SiH4	SiH4(0-50)ppm	0.2	50	5	10	1-300-012
120 Day Phosgene	COCl2	COCl2(0-1000)ppb	8.9	1000	100	200	1-200-012
120 Day Phosgene	COCl2	COCl2(0-300)ppb	3.9	300	100	200	1-200-012
120 Day Phosgene	COCl2	COCl2(0-3250)ppb	8.8	3250	100	200	1-200-012
120 Day Phosgene	COCl2	COCl2(0-5000)ppb	8.8	5000	100	200	1-200-012
120 Mineral Acids	HCL	HCL(0-15)ppm	0.2	15	5	10	1-400-012
120 Mineral Acids	HF	HF(0-10)ppm	0.2	10	3	6	1-400-012
120 Mineral Acids	BF3	BF3(0-3200)ppb	72.2	3200	1000	2000	1-400-012
120 Mineral Acids	HBR	HBR(0-20)ppm	0.2	20	3	6	1-400-012
60 Day Hydrides	AsH3	AsH3(0-500)ppb	4.7	500	50	100	1-300-010
60 Day Hydrides	B2H6	B2H6(0-1000)ppb	31.5	1000	100	200	1-300-010
60 Day Hydrides	PH3	PH3(0-1500)ppb	8.4	1500	300	600	1-300-010
60 Day Hydrides	SiH4	SiH4(0-50)ppm	0.7	50	5	10	1-300-010
60 Day Hydrides	H2S	H2S(0-25)ppm	0.1	25	10	20	1-300-010
60 Day Mineral Acids	HCL	HCL(0-15)ppm	0.2	15	5	10	1-400-010
60 Day Mineral Acids	HF	HF(0-10)ppm	0.3	10	3	6	1-400-010
60 Day Mineral Acids	BF3	BF3(0-3200)ppb	72.1	3200	1000	2000	1-400-010
60 Day Mineral Acids	HBR	HBR(0-20)ppm	0.2	20	3	6	1-400-010
60 Day Phosgene	COCl2	COCl2(0-1000)ppb	8.9	1000	100	200	1-200-010
60 Day Phosgene	COCl2	COCl2(0-4000)ppb	8.9	4000	100	200	1-200-010
Acetic Acid	Acetic Acid	Acetic Acid(0-50) ppb	0.7	50	10	20	1-490-010
Bromine	Br2	Br2(0-1000)ppb	68.8	1000	100	200	1-490-062
Chlorine	CL2	CL2(0-2000)ppb	6.9	2000	500	1000	1-500-010
COS	COS	COS(0-20)ppm	0.9	20	5	10	1-300-062
HCN	HCN	HCN(0-2500)ppb	298.2	2500	500	1000	1-800-010
Hydrazine	N2H4	N2H4(0-500)ppb	4.3	500	5	10	1-D11-010
Low Level Chlorine	CL2	CL2(0-30)ppb	1.0	30	5	10	1-500-014
Low Level Hydrides	H2Se	H2Se(0-500)ppb	5.1	500	50	100	1-300-012
Low Level Hydrides	AsH3	AsH3(0-50)ppb	0.9	50	5	10	1-300-012
Low Level Hydrides	GeH4	GeH4(0-2000)ppb	62.1	2000	200	400	1-300-012

Low Level Hydrides	PH3	PH3(0-300)ppb	4.8	300	50	100	1-300-012
MIC	MIC	MIC(0-100)ppm	3.7	100	10	20	1-600-010
NO2	NO2	NO2(0-100)ppm	0.3	100	3	6	1-600-511
Oxidizers	CL2	CL2(0-3200)ppb	50.1	3200	500	1000	1-550-010
Oxidizers	NO2	NO2(0-30)ppm	1.3	30	3	6	1-550-010
Oxidizers	F2	F2(0-3200)ppb	105.6	3200	1000	2000	1-550-010
Pyrolyzer - M/A	C5F8	C5F8(0-15)ppm	0.5	15	2	4	1-400-014
Pyrolyzer - M/A	NF3	NF3(0-15)ppm	0.5	15	2	4	1-400-014
Velcorin	DMDC	DMDC(0-200)ppb	8.8	200	40	80	1-200-030

## Appendix F – USB Memory Stick Data

To ensure that historical and performance information is stored properly be sure to insert a USB Memory Stick in the proper slot at all times. See section 6.6 for installation instructions.

The USB Memory Stick stores all information in standard comma separated values (\*.CSV) format for easy access with any computer. Remove the USB Memory Stick from the CL4/CL8 as described in section 6.6 and transfer the files to your personal computer\*. The files are best viewed with programs that convert CSV format to rows and columns (Microsoft Excel, OpenOffice, etc) but could be viewed with any standard text editor.

Figure B.1 below shows the folders and files found on the USB Memory Stick depending on the configuration or your CL4/CL8 and the use of the USB Memory Stick.




Figure B.1

### F.1 Alarm & Event files (ZG\*.CSV)

A portion of a typical event file when viewed with a spreadsheet program is shown below. Since the messages are written in reverse chronological order the recovery time shown is above the time of occurrence of the message.

**NOTE:** The columns labeled 'Acknowledge Time', 'No. of Occ', and 'Acc Time' are for DOD use only.

Trigger Date	Trigger Time	Message(s)	Acknowledge Time	Recovery Time	No. of occ.	Acc. time	Level
11/7/2006	17:32:00	8 Hour - no conc. all points.			36	0:14:17	7
		8 Hour - no conc. all points.		9:32:20	36	0:14:17	7
11/7/2006	9:32:00	8 Hour - no conc. all points.			36	0:14:17	7
		8 Hour - no conc. all points.		1:32:21	36	0:14:17	7
11/7/2006	1:32:00	8 Hour - no conc. all points.			36	0:14:17	7
		8 Hour - no conc. all points.		17:32:32	36	0:14:17	7
11/6/2006	17:32:00	8 Hour - no conc. all points.			36	0:14:17	7
11/6/2006	9:32:01	Analysis Start Time			13	35:13:06	7

## F.2 TWA Data Logs (TYMMDD.CSV)

The time weighted average information is stored on the USB Memory Stick in the TWA folder. A new file is started each day (named with the year, month, and day) for easy retrieval. Below is a sample of one cycle stored in a file.

DOD Technologies INC																
http://www.dodtec.com																
Analysis Cycle	4															
Start Date/Time	4/11/2007			22:58												
End Date/Time	4/12/2007			6:58												
Analysis Time	8:00															
Point		1		2		3		4		5		6		7		8
Gas	AsH3		AsH3	AsH3		AsH3		AsH3		AsH3		AsH3		AsH3		AsH3
Avg Conc.		0		0		0		0		0		0		0		0
Peak Conc.		0		0		0		0		0		0		0		0
Peak 15 Min Avg. Conc.		0		0		0		0		0		0		0		0
Peak 15 Min Avg. Date		0		0		0		0		0		0		0		0
Peak 15 Min Avg. Time		0		0		0		0		0		0		0		0

## F.3 Concentration Log Files (ZL\*.CSV)

When gas is detected a log file is written to the USB Memory Stick (if installed) based on the configuration settings – see section 4.5. Below is a sample of the file format stored on the USB Memory Stick - all 4/8 points are logged regardless of where the gas is detected.

Date	Time	1	2	3	4	5	6	7	8
07/03/09	07:26:11 PM	0	0	1.2	0	0	0	0	0
07/03/09	07:26:13 PM	0	0	1.2	0	0	0	0	0
07/03/10	12:19:40 AM	0	0	1.2	0	0	0	0	0
07/03/10	12:19:42 AM	0	0	1.2	0	0	0	0	0
07/03/10	12:19:44 AM	0	0	1.6	0	0	0	0	0
07/03/10	12:19:46 AM	0	0	1.6	0	0	0	0	0
07/03/10	12:19:48 AM	0	0	2	0	0	0	0	0

## F.4 Config File

A configuration file is created on the USB Memory Stick each time the ChemLogic 4/8 is powered on. The config file stores basic information about the machine including version information, serial number, customer name (if entered), etc. All of the information is stored in CSV format for easy viewing.

## Appendix G – ChemLogic Cassettes

DOD ChemLogic cassettes are designed for use in colorimetric based gas monitoring systems. Since this is a particular end-use function and does not release or result in exposure to hazardous chemicals under normal use Material Safety Data Sheets (MSDS) are not required.

**ChemLogic cassettes are non-toxic and require no special precautions for protection.**

However, contact with skin may cause the cassette to react, change color, and no longer be useful in your gas monitoring system. We therefore recommend that rubber gloves be worn at all times while handling including removal and installation. Always wash hands as a precaution after handling DOD ChemLogic cassettes.

## Appendix H – Optic Block Cleaning Procedure

The CL4/CL8 may require periodic cleaning of the optics block when the instrument is used in environments with a high level of airborne particulate or a “High Background” Fault has been reported.

There are two methods for cleaning the optics. One is a basic cleaning using canned air and the other is a more in-depth cleaning that requires the fiber optics to be cleaned with alcohol.

In most cases the basic cleaning will be enough to clear an optics fault and return the DAC to normal operating levels.

### H.1 Basic Optics Cleaning

- 1) Exit analysis mode and go to the load tape screen.
- 2) Open the gate and remove the tape.
- 3) Remove the optic block covers and the four screws holding in the optic blocks. (Figure 1)




Figure 1



Figure 2

- 4) Pull block towards you until the pins holding the block in are loose (Figure 2)
- 5) Without removing any tubes, turn block so the bottom is facing out. (Figure 3)



Figure 3

- 6) Using canned air, blow out the channels on the block with high DAC values (Figure 3)
- 7) Re-Install the blocks and close the gate.
- 8) Press just below the top left corner in the load tape screen until the enter password screen appears. (Figure 4)




Figure 4



Figure 5

- 9) Enter 1225 for the password then press "Enter".
- 10) You should see the calibrate optics screen (Figure 5), then make sure the gate is closed and press "Calibrate".
- 11) If the DAC values are 140 or below you are done. Go to "Main Menu" and clear the original faults and re-enter analysis.
- 12) If the DAV values are not lower than 140, follow the advanced cleaning instructions below.

## H.2 Advanced Optics Cleaning

- 1) Repeat above steps 1-5.
- 2) Using a cotton swab and alcohol (you may have to trim the cotton swab to fit) clean each channel that has a DAC above 140. (Figure 6)



Figure 6

- 3) Repeat above steps 7-11
- 4) If the DAC values still have not improved contact CL4/CL8 technical support at (815)-788-5200