

General Combustible 5000ppm Sensor Data Sheet (Calibrated for Acetylene)

Sensor response may vary slightly from sensor to sensor. All sensor cells can experience changes in output if exposed to rapidly changing temperature and humidity. Ensure sensors are located in areas not subject to changes in humidity and temperature.

All sensors are shipped pre-calibrated. Sensors should be gas calibrated if in use beyond 12 months.

Gas Measured	Acetylene
Sensor Module Part Number	CHS7F2F40-C2H2
Sensor Type	Platinum Hot Wire
Range	0 – 5000 ppm
Minimum Alarm Set Point	500 ppm
Lower Detectable Limit	250 ppm
Response Time	< 15 Seconds at 3-meter tubing length
Repeatability	+/-5%
Sensor Module Life Expectancy	7-10 years with annual calibration
Calibration Gas	Acetylene
Challenge Gas	CH4, H2
Humidity Operating Range	30-85% RH (Steady State)
Temperature Operating Range	-5° to 40° Celsius (Steady State)
Warm Up Time	<30 Minutes
Storage Temperature	+5° to 25° Celsius

For more information on sensors or pricing and availability, please contact DOD Technologies, Inc. at 815-788-5200