

Methane 1000ppm Sensor Data Sheet

Sensor response may vary slightly from sensor to sensor. All sensor cells can experience changes in output if exposed to rapidly changing temperature and humidity. Ensure sensors are located in areas not subject to changes in humidity and temperature.

All sensors are shipped pre-calibrated. Sensors should be gas calibrated if in use beyond 12 months.

Gas Measured	Methane (CH ₄)
Sensor Module Part Number	CHS-7F1C70
Sensor Type	Platinum Hot Wire
Range	0 – 1000 ppm
Minimum Alarm Set Point	1000 ppm
Lower Detectable Limit	500 ppm
Response Time	< 15 Seconds at 3-meter tubing length
Repeatability	+/-5%
Sensor Module Life Expectancy	7 - 10 years with annual calibration
Calibration Gas	CH ₄ 5000ppm
Challenge Gas	CH ₄ or other combustible gases (Except H ₂)
Humidity Operating Range	30-85% RH (Steady State)
Temperature Operating Range	-5° to 40° Celsius (Steady State)
Warm Up Time	<30 Minutes
Storage Temperature	+5° to 25° Celsius

Cosmos sensors have excellent specificity to target gases. Even with this excellent specificity, sensors may have cross interferences to other gases, which can result in gas readings when exposed to non-target gases. Refer to "Interferences Gases Table" for this data.

For more information on sensors or pricing and availability, please contact DOD Technologies, Inc. at 815-788-5200

Note: This sensor will not detect Hydrogen (H₂)